
Power Optimizer

For North America

P1101



POWER OPTIMIZER

PV power optimization at the module level

The most cost-effective solution for commercial and large field installations

- Specifically designed to work with SolarEdge inverters
- High efficiency with module-level MPPT, for maximized system energy production and revenue, and fast project ROI
- Superior efficiency (99.5%)
- Balance of System cost reduction; 50% less cables, fuses, and combiner boxes; over 2x longer string lengths possible
- Fast installation with a single bolt
- Advanced maintenance with module-level monitoring
- Module-level voltage shutdown for installer and firefighter safety
- Meets NEC requirements for arc fault protection (AFCI) and Photovoltaic Rapid Shutdown System (PVRSS)

Power Optimizer

For North America

P1101

Power Optimizer Model (Typical Module Compatibility)	P1101 (for up to 2 x high power or bi-facial modules)	Units	
INPUT			
Rated Input DC Power ⁽¹⁾	1100	W	
Connection Method	Single input for series connected modules		
Absolute Maximum Input Voltage (Voc at lowest temperature)	125	Vdc	
MPPT Operating Range	12.5 – 105	Vdc	
Maximum Short Circuit Current (Isc)	14.1	Adc	
Maximum Short Circuit Current per Input (Isc)	-	Adc	
Maximum Efficiency	99.5	%	
Weighted Efficiency	98.6	%	
Oversvoltage Category	II		
OUTPUT DURING OPERATION (POWER OPTIMIZER CONNECTED TO OPERATING SOLAREEDGE INVERTER)			
Maximum Output Current	18	Adc	
Maximum Output Voltage	80	Vdc	
OUTPUT DURING STANDBY (POWER OPTIMIZER DISCONNECTED FROM SOLAREEDGE INVERTER OR SOLAREEDGE INVERTER OFF)			
Safety Output Voltage per Power Optimizer	1 ± 0.1	Vdc	
STANDARD COMPLIANCE			
Photovoltaic Rapid Shutdown System	Compliant with NEC 2014, 2017, 2020		
EMC	FCC Part 15 Class A, IEC61000-6-2, IEC61000-6-3		
Safety	IEC62109-1 (class II safety), UL1741, UL3741, CSA C22.2#107.1		
Material	UL94 V-0, UV resistant		
RoHS	Yes		
INSTALLATION SPECIFICATIONS			
Compatible SolarEdge Inverters	All commercial three phase inverters		
Maximum Allowed System Voltage	1000	Vdc	
Dimensions (W x L x H)	129 x 162 x 59 / 5.1 x 6.4 x 2.32	mm / in	
Weight	1064 / 2.34	gr / lb	
Input Connector	MC4 ⁽²⁾		
Input Wire Length Options	1	1.6 / 5.2	m / ft
	2		
	3		
Output Wire Type / Connector	Double insulated; MC4		
Output Wire Length	2.4 / 7.8	m / ft	
Operating Temperature Range ⁽³⁾	-40 to +85 / -40 to +185	°C / °F	
Protection Rating	IP68 / NEMA6P		
Relative Humidity	0 – 100	%	

(1) Rated power of the module at STC will not exceed the Power Optimizer "Rated Input DC Power". Modules with up to +5% power tolerance are allowed.

(2) For other connector types please refer to the [Power Optimizer Input Connector Compatibility Technical Note](#).

(3) For ambient temperatures above +70°C / +158°F power de-rating is applied. Refer to [Power Optimizers De-Rating Application Note](#) for more details.

PV System Design Using a SolarEdge Inverter ⁽⁴⁾⁽⁵⁾		208V Grid SE10K	208V Grid SE17.3K*	277/480V Grid SE30K	277/480V Grid SE40K*	
Compatible Power Optimizers		P1101				
Minimum String Length	Power Optimizers	8	10	14	14	
	PV Modules	15	19	27	27	
Maximum String Length	Power Optimizers	30	30	30	30	
	PV Modules	60	60	60	60	
Maximum Continuous Power per String		7200	8820	15300	15300	W
Maximum Allowed Connected Power per String ⁽⁶⁾		1 string – 8400	1 string – 10020	1 string – 17550	2 strings or less – 17550	W
		2 strings or more – 9800	2 strings or more – 12020	2 strings or more – 20300	3 strings or more – 20300	
Parallel Strings of Different Lengths or Orientations		Yes				
Maximum Difference in Number of Power Optimizers Allowed Between the Shortest and Longest String Connected to the Same Inverter Unit		5 Power Optimizers				

* The same rules apply for Synergy units of equivalent power ratings, that are part of the modular Synergy Technology inverter.

(4) For each string, a Power Optimizer may be connected to a single PV module if 1) each Power Optimizer is connected to a single PV module or 2) it is the only Power Optimizer connected to a single PV module in the string.

(5) Design with three phase 208V inverters is limited. Use the [SolarEdge Designer](#) for verification.

(6) To connect more STC power per string, design your project using [SolarEdge Designer](#).